



## IMPORTANT RECALL NOTICE

Mattel, in cooperation with the United States Consumer Product Safety Commission is voluntarily recalling a number of Polly Pocket™, Barbie® Doll and Tanner™, Batman™ Magna, Doggie Daycare™ and Shonen Jump's One Piece™ playsets containing small powerful magnets. The magnets inside these dolls and accessories can fall out -- undetected to parents and caregivers. These magnets can be swallowed or aspirated by young children or placed by a child in their nose or ears. When more than one magnet is swallowed, the magnets can attract to each other and cause intestinal perforation, infection or blockage, which can be fatal. Aspiration to the lungs requires immediate surgery. Magnets placed in the nose or ears can cause swelling and be difficult to remove.

Please check your home, play areas and toys for any loose or liberated magnets—remove these from the reach of children. Discontinue use of magnetic playsets matching these descriptions and use this guide to determine if they are affected by this recall. Full color images of every product are included on subsequent pages. Use these images as a guide to identify the products you own. Enter applicable data on the final two pages of this brochure and return to us, along with any part(s)/product(s) you have deemed affected, using the prepaid mailing label you received.

### J9472 and J9560 Barbie® Doll and Tanner™


The affected part involved in this recall is the blue scooper with a magnet at the tip, which is used to pick up the plastic-coated metal pellets (the pellets are not magnets).

Please examine the end of the blue scooper. If a silver metal tip is revealed your product is affected and you should return your scooper to us for a replacement. If your scooper has a white plastic tip, you are not affected by this recall. If your scooper is purple, you are not affected by this recall.

Please complete the form on final pages and use the prepaid mailing label to return affected scooper(s) for replacement.

J9472 Barbie® and Tanner™	J9560 Barbie® and Tanner™
	
Product Number Location: Not on product.	Product Number Location: Not on product.

Unaffected product with white plastic tip.



Affected product with silver metal tip.



# The Batman™ Magna Fight Armor™ and One Piece™ Triple Slash™ Zolo Roronoa™

The Batman™ Magna Fight Armor™ figures are soft bodied with plastic accessories. The One Piece™ Triple Slash™ Zolo Roronoa™ is a hard plastic figure with plastic accessories.

Using the images below, determine if you own any of these products. All are affected by this recall. Please fill out the last two pages of this pamphlet and, using the prepaid mailing label, return affected product(s) for a voucher.

**J1944 The Batman™ Magna Battle Armor™ Batman™ Figure**



Product Number Location: On back of neck on black cowl, also on fabric tag.

**J5115 The Batman™ Magna Fight Armor™ Flying Fox™ Batman™ Figure**



Product Number Location: On back of neck on black cowl, also on fabric tag.

**J4142 One Piece™ Triple Slash™ Zolo Roronoa™**



Product Number Location: On back of left thigh.

**J5114 The Batman™ Magna Fight Armor™ Secret I.D.™ Batman™ Figure**



Product Number Location: On back of neck on black cowl, also on fabric tag.

**J1946 The Batman™ Magna Fight Armor™ Batman™ Figure**














Product Number Location: On back of neck on black cowl, also on fabric tag.

## Doggie Daycare™

Doggie Daycare™ products are small hard-bodied plastic dogs with baby dolls and many other accessories.

Using the images below, determine if you own any of these products. All are affected by this recall. Please fill out the last two pages of this pamphlet and, using the prepaid mailing label, return affected product(s) for a voucher.

<b>G9703 Doggie Daycare™ Puppy Park with Dixie Playset</b>		<b>H1532 Doggie Daycare™ Coco™ and Baby Playset</b>	<b>H1530 Doggie Daycare™ Ice Cream with Ranger™ Playset</b>
			
Product Number Location: On the bottom of the carousel.		Product Number Location: Not on product.	Product Number Location: On the back of the baby or the bottom of the dog or cart.
<b>H1533 Doggie Daycare™ Sparky™ and Baby Playset</b>	<b>G4458 Doggie Daycare™ Bath Time with Beau™ Playset</b>	<b>G4457 Doggie Daycare™ Dreamhouse Nursery with Honey™ Playset</b>	<b>G4461 Doggie Daycare™ Lulu™ and Baby</b>
			
Product Number Location: Not on product.	Product Number Location: On main component	Product Number Location: On bottom of house.	Product Number Location: On back of mirror.
<b>G4462 Doggie Daycare™ Croquette™ and Baby Playset</b>	<b>G4464 Doggie Daycare™ Taffy™ and Baby Playset</b>	<b>G4460 Doggie Daycare™ Diaper Change with Ginger™ Playset</b>	<b>G4459 Doggie Daycare™ Snacktime With Cookie™ Playset</b>
			
Product Number Location: On bottom of wagon.	Product Number Location: Not on product.	Product Number Location: On back side of changing table at the bottom.	Product Number Location: On main component



# Polly Pocket!™

Affected fashions and other accessories have magnets that are visible from the backside of the part, appearing as a small silver button. Unaffected fashion pieces will have a white coating over the magnets as shown below. The accessories which came with these fashions are also unaffected. These magnets may have a clear or colored coating or cover.

Using the images and product numbers below, determine if you own any of these products. All are affected by this recall. Please fill out the last two pages of this pamphlet and, using the prepaid mailing label, return affected product(s) for a voucher.

Please return the entirety of each affected product, including all accessory pieces.



## 55503 Polly Pocket!™ Happenin' Pet Salon™ Playset



Product Number Location: Not on product.

## J1681 Polly Pocket!™ Pollyworld™ Rockin' Theme Park™ Playset







Product Number Location: On bottom of playset.

<p><b>B3204 Polly Pocket!™ School Time Fun™ Activity Locker Pink</b></p>	<p><b>B3207 Polly Pocket!™ Lip Gloss Studio™ Playset</b></p>	<p><b>B3209 Polly Pocket!™ Glitter Boutique™ Playset</b></p>	<p><b>B3210 Polly Pocket!™ Polly Place™ Dip n' Dive Pool™ Playset</b></p>
			
<p>Product Number Location: On back of locker case.</p>	<p>Product Number Location: On back of purple lipstick case.</p>	<p>Product Number Location: On bottom pink semi-circular base.</p>	<p>Product Number Location: On bottom of jacuzzi platform.</p>
<p><b>B3211 Polly Pocket!™ Polly Place™ Gameroom Garage™ Playset</b></p>	<p><b>B3396 Polly Pocket!™ Birthday Surprise</b></p>	<p><b>B7078 Polly Pocket!™ Dazzlin' Pet Show™ Divine Dogs™</b></p>	<p><b>B7082 Polly Pocket!™ Dazzlin' Pet Show™ Magic Rabbits™</b></p>
			
<p>Product Number Location: On bottom of game room.</p>	<p>Product Number Location: Not on product.</p>	<p>Product Number Location: On bottom of product.</p>	<p>Product Number Location: On bottom of trunk.</p>
<p><b>B7118 Polly Pocket!™ Totally Polly Tiki™ Diner™ Playset</b></p>	<p><b>B7125 Polly Pocket!™ Sweet Treats™ Playsets</b></p>	<p><b>B7127 Polly Pocket!™ Mailbox Surprise™ Playset</b></p>	<p><b>B7129 Polly Pocket!™ Jewelry Box Bedroom™ Playset - Purple</b></p>
			
<p>Product Number Location: On bottom of green base of diner.</p>	<p>Product Number Location: On bottom of sweets shop.</p>	<p>Product Number Location: On right side of mailbox.</p>	<p>Product Number Location: On bottom surface of jewelry box.</p>
<p><b>B8478 Polly Pocket!™ Polly Place Party On The Go!™ Magnet Bus</b></p>	<p><b>B9521 Polly Pocket!™ Spa Day™ Playset</b></p>	<p><b>B9522 Polly Pocket!™ Lunchbox Cafe™ Playset</b></p>	<p><b>C0504 Polly Pocket!™ Mailbox Surprise™ Playset</b></p>
			
<p>Product Number Location: On bottom of tour bus.</p>	<p>Product Number Location: On bottom orange make up box.</p>	<p>Product Number Location: On back of Lunchbox</p>	<p>Product Number Location: On right side of mailbox.</p>



<b>B3158 Polly Pocket!™ Polly Place™ Treetop Clubhouse™ Playset</b>		<b>C0505 Polly Pocket!™ Jewelry Box Bedroom™ Playset</b>	<b>C1341 Polly Pocket!™ Disco Lamp</b>
			
Product Number Location: On bottom of green base.		Product Number Location: On bottom of jewelry box.	Product Number Location: On bottom of lamp platform.
<b>G8602 Polly Pocket!™ Mermaid Stars™ Playset</b>	<b>G8605 Polly Pocket!™ Quik-Clik™ Boutique</b>	<b>G8612 Polly Pocket!™ Snow Cool™ Hotel Playset</b>	<b>C1342 Polly Pocket!™ Disco Lamp</b>
			
Product Number Location: On bottom of product.	Product Number Location: On bottom of product.	Product Number Location: On the bottom of the playset.	Product Number Location: On bottom of lamp platform.
<b>G8614 Polly Pocket!™ Quik-Clik™ House Of Style™ Playset</b>	<b>G8615 Polly Pocket!™ Totally Bead-iful™ Jewelry Maker</b>	<b>H1537 Polly Pocket!™ Quik-Clik™ City Pretty™ Playset (Lila®)</b>	<b>J9966 Polly Pocket!™ Pollyworld™ Kerstie Fashions</b>
			
Product Number Location: On bottom of base.	Product Number Location: On bottom of the play set.	Product Number Location: On bottom of product.	Product Number Location: On the main component.
<b>H1553 Polly Pocket!™ Quik-Clik™ Movie Time™ Playset (Lila®)</b>	<b>H1554 Polly Pocket!™ Quik-Clik™ Pool Party® Playset (Lila®)</b>	<b>H3211 Polly Pocket!™ Quik-Clik™ Totally Zen™ Playset (Shani™)</b>	<b>H1538 Polly Pocket!™ Quik-Clik™ Sporty Style™ Playset (Lea™)</b>
			
Product Number Location: Not on product	Product Number Location: Not on product	Product Number Location: On bottom of product.	Product Number Location: On bottom of product.

<b>J1687 Polly Pocket!™ Pollyworld™ Dress N' Dive™ Lounge Playset</b>		<b>J1670 Polly Pocket!™ Stickin' 2 Style™ Doll</b>	<b>J1662 Polly Pocket!™ Pollywood™ Dial-A-Style™ Lea™ Doll</b>
			
Product Number Locaton: On bottom of driver.		Product Number Location: Printed on back 3 foot tall Polly.	Product Number Location: Not on product.
		<b>J1661 Polly Pocket!™ Pollywood™ Dial-A-Style™ Lila® Doll</b>	<b>J1695 Pollyworld™ Theme Park Party™ Quick Klik™ Doll And Fashions</b>
			
		Product Number Location: Not on product.	Product Number Location: Not on product.
<b>J4169 Polly Pocket!™ Pollyworld™ Quik Klik™ Polly™ Doll</b>	<b>J4170 Polly Pocket!™ Pollyworld™ Quik Klik™ Crissy™ Doll</b>	<b>J4171 Polly Pocket!™ Pollyworld™ Quik Klik™ Lea™ Doll</b>	<b>J4172 Polly Pocket!™ Pollyworld™ Quik Klik™ Shani!® doll</b>
			
Product Number Location: Not on product.	Product Number Location: Not on product.	Product Number Location: Not on product.	Product Number Location: Not on product.
<b>J9305 Polly Pocket!™ Pollyworld™ Costume Cart (Lea®) Playset</b>	<b>J9306 Polly Pocket!™ Pollyworld™ Gift Shop (Lila®) Playset</b>	<b>J9648 Polly Pocket!™ Twirl &amp; Swirl™ Beauty Case</b>	<b>J9965 Polly Pocket!™ Pollyworld™ Dial-A Song Polly Fashions</b>
			
Product Number Location: On bottom of product.	Product Number Location: On bottom of product.	Product Number Location: On bottom of case.	Product Number Location: Not on product.



<b>B9523 Polly Pocket!™ School Time Fun™ Playset</b>	<b>B9525 Polly Pocket!™ Glitter Puff</b>	<b>B9578 Polly Pocket!™ Spa Day™ Playset</b>	<b>B9929 Polly Pocket!™ Boutique On The Go™ Playset</b>
			
Product Number Location: On back of locker.	Product Number Location: On bottom of purple semicircular base.	Product Number Location: Not on product.	Product Number Location: On back of blue mirror.
<b>B2632 Polly Pocket!™ Polly Place™ Hangin' Out House™ Playset</b>	<b>K3460 Pollyworld Rockin' Tour Bus</b>	<b>B3201 Polly Pocket!™ Spa Day™ Caboodle Asst.</b>	<b>B3203 Polly Pocket!™ Lunchbox Cafe™ Playset</b>
			
Product Number Location: Not on product.	Product Number Location: On bottom of tour bus	Product Number Location: Not on product.	Product Number Location: On back of lunchbox.

**J1659 Polly Pocket!™ Pollywood™ Limo-Scene™ Vehicle**

**J1659 Polly Pocket!™ Pollywood™ Limo-Scene™ Vehicle**

Please locate the 6 character alphanumeric code ending in the letters HF.  
This code will found on the bottom of the limo, between the front tires.

**If your code ends in 5HF or 6HF your product is affected.**

**If your code ends in 7HF and the first 3 digit are 001 to 129 your product is affected.**

If your code ends in 7HF and the first 3 digit are higher than 129, your product is not affected.



**Product Number Location:** On bottom of product.  
**DOM Location:** On bottom of product.



# Mattel Playsets with Magnet Hazard - Recall Returns Form

(Please include this page with your return)

- Identify the product you own — using the images on previous pages as your guide.
- Input the quantity of affected product you own for each product number you have deemed affected and multiply that by the voucher amount for your country. Fill in Total.
- Add up Section Totals & Grand Total — if your returns match your form, this is the voucher amount you will receive.
- Fill in your contact information below, package ALL affected products into ONE package ( follow package size instructions from letter or email) — include these two pages — affix prepaid mailing label to package and take to the post office.

Barbie® Doll and Tanner™ Products			
Page #	Prod. #	Description	Quantity Returned
1	J9472	Barbie® Doll & Tanner™ - Blue Scooper	
1	J9560	Barbie® Doll & Tanner™ - Blue Scooper	

One Piece™ Triple Slash™ Zolo Roronoa™				Multiply Quantity by Amount for Total			
Page #	Prod. #	Description	Quantity Returned		U.S. Voucher Amount	Canadian Voucher Amount	Total
2	J4142	One Piece™ Triple Slash™ Zolo Roronoa™		x	\$6	\$7	
Total 1:							

The Batman™ Magna Figures				Multiply Quantity by Amount for Total			
Page #	Prod. #	Description	Quantity Returned		U.S. Voucher Amount	Canadian Voucher Amount	Total
2	J1944	The Batman™ Magna Battle Armor™ Batman™ Figure		x	\$8	\$9	
2	J1946	The Batman™ Magna Fight Wing™ Batman™ Figure		x	\$10	\$11	
2	J5115	The Batman™ Magna Flying Fox™ Batman™ Figure		x	\$11	\$12	
2	J5114	The Batman™ Magna Secret I.D.™ Batman™ Figure		x	\$13	\$14	
Total 2:							

Doggie Daycare™ Products				Multiply Quantity by Amount for Total			
Page #	Prod. #	Description	Quantity Returned		U.S. Voucher Amount	Canadian Voucher Amount	Total
3	G4457	Doggie Daycare™ Dreamhouse Nursery With Honey™ Playset		x	\$15	\$16	
3	G4458	Doggie Daycare™ Bathtime With Beau™ Playset		x	\$10	\$11	
3	G4459	Doggie Daycare™ Snacktime With Cookie™ Playset		x	\$6	\$7	
3	G4460	Doggie Daycare™ Diaper Change with Ginger™ Playset		x	\$8	\$9	
3	G4461	Doggie Daycare™ Lula™ and Baby Playset		x	\$4	\$5	
3	G4462	Doggie Daycare™ Crockett™ and Baby Playset		x	\$4	\$5	
3	G4464	Doggie Daycare™ Taffy™ and Baby Playset		x	\$3	\$4	
3	G9703	Doggie Daycare™ Puppy Park With Dixie™ Playset		x	\$25	\$27	
3	H1530	Doggie Daycare™ Icecream With Ranger™ Playset		x	\$7	\$8	
3	H1532	Doggie Daycare™ CoCo™ and Baby Playset		x	\$5	\$6	
3	H1533	Doggie Daycare™ Sparly™ and Baby Playset		x	\$5	\$6	
Total 3:							

Polly Pocket!™ Products				Multiply Quantity by Amount for Total			
Page #	Prod. #	Description	Quantity Returned		U.S. Voucher Amount	Canadian Voucher Amount	Total
4	55503	Polly Pocket!™ Fashion Polly® Happenin' Pet Salon™ Playset		x	\$10	\$11	
8	B2632	Polly Pocket!™ Polly Place™ Hangin' Out House™ Playset		x	\$21	\$23	
6	B3158	Polly Pocket!™ Polly Place™ Treetop Clubhouse™ Playset		x	\$10	\$11	
8	B3201	Polly Pocket!™ Spa Day™ Caboodle Asst.		x	\$8	\$9	
8	B3203	Polly Pocket!™ Lunchbox Café™ Playset		x	\$7	\$8	
5	B3204	Polly Pocket!™ School Time Fun™ Playset		x	\$7	\$8	
5	B3207	Polly Pocket!™ Lip Gloss Studio™ Playset		x	\$7	\$8	
5	B3209	Polly Pocket!™ Glitter Boutique™ Playset		x	\$5	\$6	
5	B3210	Polly Pocket!™ Polly Place™ Dip N' Dive Pool™ Playset		x	\$10	\$11	
5	B3211	Polly Pocket!™ Polly Place™ Gameroom Garage™ Playset		x	\$7	\$8	
Total 4:							

Polly Pocket!™ Products (Continued)			Multiply Quantity by Amount for Total				
Page #	Prod. #	Description	Quantity Returned		U.S. Voucher Amount	Canadian Voucher Amount	Total
5	B3396	Polly Pocket!™ Birthday Surprise		x	\$7	\$8	
5	B7078	Polly Pocket!™ Dazzlin' Pet Show™ Divine Dogs™		x	\$6	\$7	
5	B7082	Polly Pocket!™ Dazzlin' Pet Show™ Magic Rabbits™		x	\$7	\$8	
5	B7118	Polly Pocket!™ Polly Place™ Totally Tiki Diner™ Playset		x	\$10	\$11	
5	B7125	Polly Pocket!™ Polly Place™ Sweet Treats™ Playset		x	\$7	\$8	
5	B7127	Polly Pocket!™ Mailbox Surprise™ Playset		x	\$8	\$9	
5	B7129	Polly Pocket!™ Jewelry Box Bedroom™ Playset		x	\$5	\$6	
5	B8478	Polly Pocket!™ Polly Place™ Party On The Go!™ Playset		x	\$9	\$10	
5	B9521	Polly Pocket!™ Spa Day™ Playset		x	\$8	\$9	
5	B9522	Polly Pocket!™ Lunchbox Cafe™ Playset		x	\$7	\$8	
8	B9523	Polly Pocket!™ School Time Fun™ Playset		x	\$7	\$8	
8	B9525	Polly Pocket!™ Glitter Puff		x	\$7	\$8	
8	B9578	Polly Pocket!™ Spa Day™ Playset		x	\$11	\$12	
8	B9929	Polly Pocket!™ Boutique On The Go™ Playset		x	\$9	\$10	
5	C0504	Polly Pocket!™ Mailbox Surprise™ Playset		x	\$7	\$8	
6	C0505	Polly Pocket!™ Jewelry Box Bedroom™ Playset		x	\$7	\$8	
6	C1341	Polly Pocket!™ Disco Lamp		x	\$11	\$12	
6	C1342	Polly Pocket!™ Disco Lamp		x	\$11	\$12	
6	G8602	Polly Pocket!™ Mermaid Stars™ Playset		x	\$11	\$12	
6	G8605	Polly Pocket!™ Quik-Clik™ Boutique		x	\$9	\$10	
6	G8612	Polly Pocket!™ Snow Cool™ Hotel Playset		x	\$21	\$23	
6	G8614	Polly Pocket!™ Quik-Clik™ House Of Style™ Playset		x	\$25	\$27	
6	G8615	Polly Pocket!™ Totally Bead-iful™ Jewelry Maker		x	\$17	\$19	
6	H1537	Polly Pocket!™ Quik-Clik™ City Pretty™ Playset (Lila®)		x	\$10	\$11	
6	H1538	Polly Pocket!™ Quik-Clik™ Sporty Style™ Playset (Lea™)		x	\$7	\$8	
6	H1553	Polly Pocket!™ Quik-Clik™ Movie Time™ Playset (Lila®)		x	\$7	\$8	
6	H1554	Polly Pocket!™ Quik-Clik™ Pool Party® Playset (Lila®)		x	\$10	\$11	
6	J9966	Polly Pocket!™ Pollyworld™ Kerstie Fashions		x	\$8	\$9	
6	H3211	Polly Pocket!™ Quik-Clik™ Totally Zen™ Playset (Shani™)		x	\$10	\$11	
8	J1659	Polly Pocket!™ Pollyworld™ Limo-Scene™ Vehicle		x	\$11	\$12	
7	J1661	Polly Pocket!™ Pollyworld™ Dial-A-Style™ Lila® Doll		x	\$10	\$11	
7	J1662	Polly Pocket!™ Pollyworld™ Dial-A-Style™ Lea™ Doll		x	\$8	\$9	
7	J1670	Polly Pocket!™ Stickin' 2 Style™ Doll		x	\$11	\$12	
4	J1681	Polly Pocket!™ Pollyworld™ Rockin' Theme Park™ Playset		x	\$28	\$30	
7	J1687	Polly Pocket!™ Pollyworld™ Dress N' Drive™ Lounge Playset		x	\$16	\$17	
7	J1695	Polly Pocket!™ Pollyworld™ Theme Park Party™ Quik Clik™ Doll and Fashions		x	\$9	\$10	
7	J4169	Polly Pocket!™ Pollyworld™ Quik Clik™ Polly™ Doll		x	\$3	\$4	
7	J4170	Polly Pocket!™ Pollyworld™ Quik Clik™ Crissy™ Doll		x	\$4	\$5	
7	J4171	Polly Pocket!™ Pollyworld™ Quik Clik™ Lea™ Doll		x	\$4	\$5	
7	J4172	Polly Pocket!™ Pollyworld™ Quik Clik™ Shanil® doll		x	\$4	\$5	
7	J9305	Polly Pocket!™ Pollyworld™ Costume Cart (Lea®) Playset		x	\$11	\$12	
7	J9306	Polly Pocket!™ Pollyworld™ Gift Shop (Lila®) Playset		x	\$8	\$9	
7	J9648	Polly Pocket!™ Twirl & Swirl™ Beauty Case		x	\$11	\$12	
7	J9965	Polly Pocket!™ Pollyworld™ Dial-A Song Polly Fashions		x	\$11	\$12	
8	K3460	Polly Pocket!™ Pollyworld™ Rockin' Tour Bus™		x	\$8	\$9	
						Total 5:	

Name:

Address 1:

Address 2:

State or Province:

Zip or Postal Code:

<b>Total of Barbie Scoopers returned for replacement:</b>	
<b>Total 1:</b>	
<b>Total 2:</b>	
<b>Total 3:</b>	
<b>Total 4:</b>	
<b>Total 5:</b>	
<b>Grand total:</b>	\$